


Connection diagram

Central gauge for 350Z.



Sensor cable
5 meters



Sensor cable
5 meters



Sensor cable
5 meters



Sensor cable
5 meters



Power cable
1 meter



Temperature sensor 1/8 NPT



Temperature sensor 1/8 NPT



Temperature sensor 1/8 NPT



Pressure sensor 1/8 NPT




Red: +12V
White: Ground

(It's depends on the options)

**CELSIUS or
FAHRENHEIT**

LHD or RHD

BAR or PSI



**Display Oil
temperature**

**Display Water
temperature**

**Display
Auxiliary
temperature**

**Display
Boost
pressure**

Sensor	Placement	Photo
Temperature oil sensor	Oil pan or oil sandwich plate with 1/8 NPT threaded hole.	
Temperature water sensor	Heater hose with 1/8 NPT threaded hole.	
Temperature auxiliar sensor	Gearbox or differential Filler hole with M18x1.5 to 1/8 NPT adapter.	
Boost pressure	On boost system with 1/8NPT threaded hole.	(It depends on the setup)

Installation video:



POST SHARED ON 19 JANUARY
BY OPENTOP_Z33_Z34